



GRONOMICS® “TOOL FREE ASSEMBLY”

RAISED GARDEN BED THREE TIER TRELLIS KIT Parts Check List and Assembly Instructions

STEP I

- A) Unpack all of the parts and organize them in ‘like’ stacks. Please read the instructions in its entirety before beginning assembly.

You should have:

Model #RGB3TTK80-96

QUANTITY	PART DESCRIPTION	PART #
Parts		
1	Trellis Net	8007
1	4” x 4” x 80” Trellis Post (Left)	7001-Lt
1	4” x 4” x 80” Trellis Post (Right)	7001-Rt
1	2” x 4” x 91½” Cross Piece	7002
Packaged & Inspected by: _____ Date _____		

NOTE: If you need assistance with parts or have assembly questions, please contact Customer Service either via email at info@cwpmulch.com or phone at 763-753-7374.



STEP II

- A) Slide the right and left trellis posts into the Raised Garden Bed frame.
- B) Slide the cross piece between the two posts.

Note: See trellis net assembly instructions.

Recommended Finish: A natural oil non film-forming finish designed for Cedar. If Cedar is not finished checking may occur and will naturally turn a weathered gray color.

1-Year Warranty: All Gronomics® products are warranted against all manufacturing defects of material or craftsmanship for a period of ONE full year from date of purchase. Warranty does not cover cracking, damage caused by negligence, alterations or abuse in any way.