



GRONOMICS®

“MINIMAL ASSEMBLY REQUIRED”

## PERGOLA PLANTER Assembly Instructions

Model #PP2 18-34

Model #PP2 18-34S

1. Unpack all of the parts and organize them in ‘like’ stacks. Please watch DVD assembly instructions and/or read the instructions in their entirety before beginning assembly.
2. Locate the two (2) tall pergola posts (Part #6103). One labeled “X” and one labeled “O” (labels are on bottom of posts).
3. Start with the left planter of the pergola. Stand up the front left post “X” (Part #6103-Lt).
  - a. The grooves in center of post should face away from you and to the right.
  - b. The cut-out notch at the top should be facing toward you, slanting from right to left.
4. Slide a 31” side rail with cleat (Part #3102) in groove facing away from you.
  - a. Make sure the cleat side is facing to your right, and on the bottom.
5. Stand up the post marked “O” (Part #6103).
  - a. The notch on the top of the post should face away from post “X”.
  - b. Lift up post “X” with the cleat and guide it into groove on post “O”.
6. Take a 32” post (Part #3201) and slide a 14½” rail into groove.
  - a. Lift and slide rail into groove in tall post “O” (Part #6103).
  - b. This section should now stand on its own.
7. Repeat step #6 with another 32” post (Part #3201).
8. Finish connecting posts with a 31” side rail with cleat (Part #3102).
9. Add two (2) matching 14½” narrow center side rails (Part #1451) and two (2) matching 31” narrow center side rails (Part #3103) to appropriate sides.
  - a. Follow with two (2) matching 14½” side rails (Part #1450) and two (2) matching 31” side rails (Part #3102).
  - b. You will have to spread the tall post slightly when adding rails between them.
10. Repeat steps #1 through 8 for the right side planter.
11. Locate a set of 2” x 8” x 64” trusses (Part #6100) (labeled with matching letters on either end).
  - a. Lie trusses on ground with letters facing each other to create the ‘roof’ of your pergola.
12. Place decorative pentagon cap (Part #7021) upside down, underneath center of trusses.
  - a. To level trusses, prop the ends up using the bottom boards not needed in this step.



GRONOMICS®

## “MINIMAL ASSEMBLY REQUIRED”

13. Center support plate (Part #7022) over center of trusses and insert a 2¾” screw (Part #7020) into each hole.
14. Position the stands so they measure 8’ from outside edges of upright posts on either stand.
15. With a helper, raise the truss into position.
  - a. With decorative cap facing out, you will see a marking on bottom of truss (where the post should line up); the upright post should be on the “X” side of the line.
16. As helper holds the truss in place, insert two (2) 2¾” screws (Part #7020) thru the inside of post into truss on each truss end.
17. Repeat step #15 for back side of truss.
18. Using two (2) 31” side rails (Part #3102), tie the upright posts together on inside top by sliding a rail into grooves on either side.
19. Place the notched 2” x 6” x 60” truss cross piece (Part #6102) on the “X” side of line and attach thru the pre-drilled holes on top with a 4” screw (Part #7018).
  - a. Continue with all six (6) 2” x 6” x 60” truss cross pieces (Part #6102).
20. After removing black protective caps off screws on 4” x 4” x 32” corner posts (Part #3201), twist a 4” post cap (Part #3100) on all four posts.
21. Place four (4) 15½” corner notched bottom boards (Part #1551) and eight (8) 15½” bottom boards (Part #1550) in planters.
22. Place fabric liner (Part #2002) in bottom of each planter.
23. Add your soil, and plant away...



**NOTE:** If you need assistance with parts or have assembly questions, please contact Customer Service either via email or at [info@cwpmulch.com](mailto:info@cwpmulch.com) or phone at 763-753-7374.

*1-Year Warranty: All Gronomics® products are warranted against all manufacturing defects of material or craftsmanship for a period of ONE full year from date of purchase. Warranty does not cover cracking, damage caused by negligence, alterations or abuse in any way.*