



GRONOMICS® “TOOL FREE ASSEMBLY”

48” x 48” x 19” RAISED GARDEN BED Parts Check List and Assembly Instructions

STEP I

A) Unpack all of the parts and organize them in ‘like’ stacks. Please read the instructions in its entirety before beginning assembly.

You should have:

Model #RGBT 48-48
Model #RGBT 48-48S

QUANTITY	PART DESCRIPTION	PART #
4	4” x 4” x 19” Corner Post	2300
Parts for the Sides		
12	45” x 5½” x 1” Side Rail (One w/logo)	4501, 4501L
Packaged & Inspected by: _____ Date _____		

NOTE: If you need assistance with parts or have assembly questions, please contact Customer Service either via email at info@gronomics.com or phone at 763-753-7374.



GRONOMICS® “TOOL FREE ASSEMBLY”

STEP II

- A) Start with two 4” x 4” x 19” corner posts, place the posts upside down.
- B) Slide one 45” x 5½” x 1” side rail between each post. (see figure 1)
- C) Repeat the same process with the other two 4” x 4” x 19” corner posts and another 45” x 5½” x 1” side rail. Make sure the 45” x 5½” x 1” side rail w/logo is placed upside down in this step.

(Figure 1)



STEP III

- A) Connect the two corner posts by sliding a 45” x 5½” x 1” side rail into each post. (see figure 2)
- B) Slide the remaining eight 45” x 5½” x 1” side rails into the posts.

(Figure 2)



STEP IV

- A) Turn right side up.

(Figure3)



Note: Ground preparation is optional, we recommend leveling area under frame of bed before placing bed and filling with soil.

1-Year Warranty: All Gronomics® Products are warranted against all manufacturing defects of material or craftsmanship for a period of ONE full year from date of purchase. Warranty does not cover cracking, damage caused by negligence, alterations or abuse in any way.