



GRONOMICS® RUSTIC SERIES
“TOOL FREE ASSEMBLY”

18” x 48” x 19” RUSTIC PLANTER BOX
Parts Check List and Assembly Instructions

STEP I

A) Unpack all of the parts and organize them in ‘like’ stacks. Please read the instructions in its entirety before beginning assembly.

You should have:

Model #RPB18-48

QUANTITY	PART DESCRIPTION	PART #
4	4” x 4” x 19” Corner Post	R1900
4	4” x 4” x 1½” Post Cap	R3100
Parts for the Sides		
4	14½” x 5½” x 1” Side Rail	R1450
2	45” x 5½” x 1” Side Rails w/Cleat	R7011
2	45” x 5½” x 1” Side Rail (One w/Logo)	R4501, R4501L
Parts for the Bottom		
2	15” x 5½” x 1” Corner Notched Bottom Board	R1552
6	15” x 5½” x 1” Bottom Board	R1550
1	18” x 48” Fabric Liner	2003
Packaged & Inspected by: _____ Date _____		

NOTE: If you need assistance with parts or have assembly questions, please contact Customer Service either via email at info@gronomics.com or phone at 763-753-7374.



GRONOMICS® RUSTIC SERIES “TOOL FREE ASSEMBLY”

STEP II

- A) Start by standing up two of the four 4” x 4” x 19” posts.
- B) Slide a 45” x 5½” x 1” side rail with cleat on bottom between the posts. (see figure 1)
- C) Repeat the same process with the other two 4” x 4” x 19” posts and 45” x 5½” x 1” side rail with cleat.

Soil depth options: The directions as printed will provide a planter box with a soil depth of approximately 10”. If you want a soil depth of approximately 6”, just reverse the position of the lower side rail with the cleat on top.

(Figure 1)



STEP III

- A) Connect the two sets of corner posts by sliding a 14½” x 5½” x 1” side rail into each post. (see figure 2)

(Figure2)



STEP IV

- A) Slide both of the remaining 45” x 5½” x 1” side rails and the 14½” x 5½” x 1” side rails into the posts. Note: Placement of the 45” x 5½” x 1” side rail w/logo. (see figure 3)

STEP V

- A) Place the two 15½” x 5½” x 1” corner notched bottom boards on the end cleats. Make sure the corner cut-out notches are in the corners.
- B) Place the remaining 15 x 5½” x 1” bottom boards on the cleats.

(Figure 3)



STEP VI

- A) Carefully remove the screw covers that are protecting the cap screws. Place the cap on the center of the screw utilizing the pre-drilled hole in bottom of the cap. - Do not over tighten. (see figure 3)
- B) Place the fabric liner on the bottom.

1-Year Warranty: All Gronomics® products are warranted against all manufacturing defects of material or craftsmanship for a period of ONE full year from date of purchase. Warranty does not cover cracking, damage caused by negligence, alterations or abuse in any way.